

---

ASSEMBLY INSTRUCTIONS FOR YOUR  
**BRUNO DOUBLE ARM  
TASK FLOOR LAMP**

**ASSEMBLY INSTRUCTIONS:**

**NOTE: Do not connect the electricity until lamp is fully assembled.**

Unpack and place all parts on a soft surface.

1. Place base (G) on level surface. Tilt base (G) on side and pull wiring between base (G) and column (F) taut. Thread nipple of column (F) into base (G). NOTE: wiring must be tight when threading parts together to avoid damaging the wire.
2. Tilt base (G) back on level surface.
3. Thread tube (A) into threaded opening of column (D).
4. Thread counterweight (B) into threaded opening of part (C). Repeat step for each counterweight (B). Counterweight (B) must be installed for lamp to function properly.
5. Loosen lock (E) (turn counterclockwise direction) and pull tube (D) to maximum height. Tighten lock (E) (turn clockwise direction) to secure height of lamp. NOTE: pull/push on cord when adjusting height of column (D).
6. Instal two (2) Type A-15, 60 watt maximum bulbs into socket. NOTE: Silver tip bulbs recommended.
7. Remove protective plastic (I) from polarized plug (H).
8. Plug lamp into wall outlet.

**Caution: To clean, use a soft cloth only. Do not use any chemical or abrasive cleaners.**

Note: Turn the power off (unplug from the wall outlet) before replacing the bulb, making sure the bulb has had sufficient time to cool down. Do not subject the lamp to any shock while lit as shattering of lamp may result.

**IMPORTANT SAFETY INSTRUCTIONS**

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce risk of electric shock, this plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. **DO NOT ALTER THE PLUG.**

